


## TERMINAL BLOCK FOR MIXED I/O



32. +12 V DC	35. GND	38. DI 2	41. RS485A-
33. +5 V DC*	36. DI 1	39. GND	42. RS485B+
34. GND	37. Transistor output	40. +3.3 V DC	43. GND

\* Maximum current on the output is 1 A. As this output is also used to power the relays (~45 mA each + safety relays ~90 mA each), the current available on this output depends on how many relays are being used.

*Last updated: 30 September, 2020*

---

T&I Technical manual: **TN-TG2-RX101-EN-v04** – Last published : **24 September, 2021**

Copyright © 2021 Tele Radio AB All rights reserved.